


## Cooking Range GL 2013



Cooking Range GL 2013		
Ref. No.	Spare Part Name	SAP Code
	8170 Oven Door Left Hinge	40000847
	9045 Oven Door Right Hinge	40000848
	9046 Oven Door Hinge Support	40000849
	Adaptor For Rottessorie Motor	40000982
	Al Pipe 2013 Bb Lh Back 235	40000924
	Al Pipe 2013 Bb Rh Front 360 Mm	40000926
	Al Pipe 2013 Sb Rh Back 235	40000925
	Al Pipe 2013 Tr Triple Ring Br 300	40000923
	Al Pipe For Grill 890	40000914
	Al Pipe For Grill 890	40000915
	Al Pipe For Oven 960	40000917
	Cr Chamber Gas	40000807
	Cr Side Panel	40000816
	Dish Warmer Door Frame	40001005
	Gas Thstat 2 Way 8706/10	40000824
	Gas Thstat 2 Way Safety8698/10	40000826
	Thcouple 0356 L=1000	40000830
	Gi Back Cover	40000980
	Heat Shield Plate Coated	40000935
	Hot Case Mounting Bkt	40001574
	Knob Dial Gas Thstat Paint & Prtd	40000955
	Ms Bottom Frame P Coated	40001006
	Ms Control Panel Enmld	40000875
	Ms Gas Pipe	40000818
	Ms Mixing Tube Holding Tray P Coat	40000811
	Ms Oven Door Enmld	40000834
	Oven Door Corner Cover	40000843
	Oven Door Handle Big	40000842
	Oven Lamp 15 Watt	40001002
	Oven Outer Glass 512x457 Ref Prtd	40000856

Ref. No.	Spare Part Name	SAP Code
	Knob Spring	50001544
	Proceline Oven Lamp Holder	40001001
	Rocker Switch Light Rott	40000976
	Rottessorie Motor	40000981
	Ss Control Panel Plate	40000886
	Ss Control Panel Plate Ffd	40000887
	Wire Harness Set	40000977
	Gas Valve S Ear N/S 0.42 Sb/Bb	40000821
	Gas Valve S Ear N/S 0.50 Sb/Bb	40001613
	Push On/Rocker Switch Cooking Range Ai	40000975