


Sandwich Maker GL 3025



Sandwich Maker GL 3025		
Ref. No.	Spare Part Name	SAP Code
1	lamp cover -Red	50002221
2	Lampcover-Green	50002222
3	Top Cover	50002292
4	Handle lock	50002223
5	Element	
6	Cook Plate	
7	Decorative Handle	50002225
11	Element fixing clamp	50002224
15	Bottom Cover	50002293
16	Foot	
18	Power Base Cover	
20	Power Cord	
22	Thermstat	50002226
24	LED wire set	