


Sandwich Maker GL 3026



Sandwich Maker GL 3026		
Ref. No.	Spare Part Name	SAP Code
24	Lead Assemble d	
23	Circular External Nut	
22	Thermostate	50002485
21	Mum Washer	
20	Power Cord	
19	Screw	
18	Block Power cord	50002484
17	screw	
16	Rubber Foot	
15	Lower Housing	50002491
14	Screw	
13	Spring washer	
12	Patch	
11	thermo Fuse Press Patch	
10	Screw	
9	Screw	
8	Screw	
7	Gripe cover	50002486
6	Grill	50002489
5	Heating Element	50002492
4	Handle Locker	50002483
3	Upper house	50002490
2	Lamp cover (Green)	50002482
1	Lamp cover (red)	50002481