


Rice Cooker GL 3056



Rice Cooker GL 3056		
Ref. No.	Spare Part Name	SAP Code
14	Power Cord	50002560
22 & 23	Semi-Switch with Lever	50002557
24	Switch Button	50002562
5	AL Inner Pot	50002555
32	Fuse	50002580
	Gift Box	50002578
13 & 28	Handle	50002559
7	Heating Plate	50002556
3	Lid	50002554
1	Lid Handle	50002558
6	Magnet Controller	50002584
34	Measuring Cup	50002565
18	Plastic Foot	50002561
33	Rice Paddle	50002564
	Swath Panel	50002563
	Warm Plate	50002582
	Panel	50002665
	Glass Lid (3056 DLX)	50002660