


Rice Cooker GL 3057



Rice Cooker GL 3057		
Ref. No.	Spare Part Name	SAP Code
14	Power Cord	50002560
24	Switch Button	50002562
5	AL Inner Pot	50002567
32	Fuse	50002581
	Gift Box	50002579
13 & 28	Handle	50002559
7	Heating Plate	50002568
3	Lid	50002566
1	Lid Handle	50002558
6	Magnet Controller	50002585
34	Measuring Cup	50002565
18	Plastic Foot	50002561
33	Rice Paddle	50002564
22 & 23	Semi-Switch with Lever	50002569
25	Swath Panel	50002563
	Warm Plate	50002583
	Cooking Plate	50002669
	Inner Steamer	50002670
	Light	50002671
	Line	50002672