


Rice Cooker GL 3058 DX



| Rice Cooker GL 3058 DX | | |
|------------------------|---------------------|----------|
| Ref. No. | Spare Part Name | SAP Code |
| | Fuse | 50002580 |
| | Gift Box | 50002655 |
| | Lever | 50002653 |
| | Non-Stick Inner Pot | 50002650 |
| | Panel | 50002652 |
| | PCB Board | 50002654 |
| | Plastic Parts | 50002651 |