


Oven Toaster Griller GL 5060



Oven Toaster Griller GL 5060		
Ref No.	Item Name	Sap Code
1	Lower Door Frame	50002959
2	Door Glass	50002960
3	Handle	50002962
10	Front Panel	50002958
16	Switch	50002965
17	Thermosat	50002963
19	Foot	50002961
23	Crumb Tray	50002966
24	Bake Tray	50002967
25	Wire Rack	50002969
26	Motor Bracket	50002972
27	Transmission Shaft	50002973
33	Power Cord	40002058
36	Tray Handle	50002969
37	Rotisserie Spit	50002971
39	Rotisserie Shaft	50002970
41	Rotisserie Bracket	50002975
43	Heating Element	50002974