

BUILT IN HOB

How to replace the glass:

- Remove the hob from platform.
- Remove all pan supports & burners.
- Remove all the knobs.
- Open 10 screws, fixed in mixing tubes.
- Remove the glass, replace it.

To check leakage:

- Generally there is no leakage in gas valves; leakage is in back nozzle due to wrong installation.
- Open the back nozzle.
- Check the gas kit, replace or refix it.
- Tight the back nozzle, check the leakage with the help of bubble tester or soap test.

How to replace catenary:

- Catenary switch has three holding locks.
- One lock of spindle and two gets locked with gas valve if defective have to replace complete.
- Remove the connectors from AI box and main wire's terminal separator.
- Replace it and fix it.
- While fixing align the gas valve, spindles for smooth operation.