

# **Electric Kettle GL 9007**

## **How to repair Kettle GL 9007:**

- Turn around the kettle on rubber mat.
- Open 4 screws of body.
- Open 3 screws of element.
- Remove bottom cover.

## **To open thermostat:**

- Remove connections and open 3 screws.
- Separate thermostat from element.
- Replace with new and refix.

## **To replace element:**

- Remove all connections.
- Remove clip ring with the help of sharp pointed screw driver.
- Press element from inside and take it out for replacement.
- Remove the thermostat from element by opening the screws.
- Take new element and fix thermostat on element.
- Place the gasket around the element carefully, keeping gasket step towards thermostat side.
- Press the element hard so can the element reach and touch four supporting ribs inside the body.
- NOTE: if the gasket will not sit properly, leakage will be there.
- Place the clip ring.
- Connect all connections.
- Screw back the base plate.

## **To change the On/Off auto cut switch:**

- To remove the handle, press the plastic handle lock from inside bottom .
- Take handle out.
- Remove the plastic knob.
- Open the screws of AI switch.
- Remove the thimbles and replace with new one.
- Fix the screws and thimbles.