

GL – 2013 PL TR AI FFD T.R. Burner

How to replace aluminum pipe:

- Open the top plate by opening 2 screws in bolt the nut from the mixing tube with the help of spanner 16-17 no
- Unbolt the nut from the gas valve joint.
- Replace it.

How to operate FFD Oven/Griller thermostat:

- Press the thermostat knob for 10-15 seconds and turn AI button on the left corner of control panel.
- Turn the knob to clockwise to turn on the grill, doing this top burner of chamber will ignite.
- Leave the knob to check whether griller flame is continued.
- Keep pressed & turn the knob anticlockwise for oven. In this oven burner at bottom will ignite.
- In this case after 15 seconds on leaving knob, if flame goes off repeat the process.

If still not working:

- Check the thermocouple mounted on thermostat.
- Open the nut with help of d/e spanner size no. 8
- Upper nut is for grill burner and lower one is for oven burner
- Clean tip of thermo couple with clean cloth to remove the moisture, dry it and fix it properly.

How to check the leakage:

Method- Bubble test

Bubble tester top point to be connected to gas cylinder regulator. Side connector will be connected with gas stove.

Procedure

Block the jet with finger tip and put the gas valve knob ON. Now gas is filled in the complete pipe line. Release finger tip gently, you will find the bubbles in the tester. Repeat the test on/sim position twice, if there is bubble then there is leakage .tight all the connecting joint from gas valve to jet and back nozzle
Repeat the test.